


RJ45 PIN	FUNCTION
1	GND
2	limit Z
3	limit Y
4	limit X
5	Not Used
6	Not Used
7	5V
8	Not Used

↕
To C32 or C35



← C27 Board or A33 Connector

PNP NC inductive sensor Connected in series

