


USB
CONNECTION



Note: If using Limits & Home Switches, use an external power supply and set the jumper for powering the board with the external power supply. Otherwise, the board may be powered from the breakout board.



Breakout Board
(C32,C23,C62)

CNC⁴PC

<http://www.cnc4pc.com>

Designed: YAC

Date: JUL-25 -2014

Revised:

Date:

Item: KT-UPK

Ver.:

Description:

POKEYS CONTROLLER USB